


Service Manual

Electronic Organ
SX-U50



Specifications

Keyboards

- Upper Manual: 44 Keys $\text{F}\sim\text{C}^4$ ($3\frac{2}{3}$ Octaves)
- Lower Manual: 44 Keys $\text{F}\sim\text{C}^3$ ($3\frac{2}{3}$ Octaves)
- Pedal Keyboard: 13 Keys $\text{C}\sim\text{C}$ (1 Octaves)

Orchestral Conductor

- Upper: Tab Voices, String Ensemble, Orchestral Presets, Percussive Presets, Solo Synthe Presets

Upper Tones

- Tab Voices: Flute 16', 8', 4', $2\frac{2}{3}$ ', 2', Brass 16', Oboe 8', String 8', 4', Percussive Tone.....4', $2\frac{2}{3}$ ', Full, Long Volume
- String Ensemble: Wah Brass, Clarinet, Accordion, Saxophone, Trombone, Full.....Harmonic Control
- Percussive Presets: Piano, Harpsichord, Vibraphone, Mandoline, Full
- Solo Synthe Presets: Violin, Trombone, Saxophone.....Pitch, Volume

Lower Tones

- Tab Voices: Flute 8', 4', Diapason 8', Horn 8', Cello 8' Tablet.....Volume
- String Ensemble: Bass 16', 8', Bass Guitar.....Volume

Pedal Tones:

Effects

- Harmonic Coupler: Upper.....On, $2\frac{2}{3}$ '/ $5\frac{1}{3}$ ' Lower.....2'
- Sustain (Tablet): Upper Sustain, Lower Sustain (Lever): Upper Sustain, Lower Sustain, Pedal Sustain On, Heavy, Delay
- Vibrato: Upper Tab Voices, Lower Tab Voices, Chorus/Tremolo.....Tremolo Speed
- Tremolo: Upper Tab Voices, Orchestral Presets, Solo Synthe Presets, Lower Tab Voices
- Celeste: Upper
- Slow Attack: Reverberation, Brilliance, Manual Balance
- Others:

Voice Setting Computer: Record, Combination, Composer I, Composer II, Cancel

Techni-Chord

Automatic Rhythm

- Rhythm Selectors: (Rhythm A/B) March/Rolling March, Swing/rumba, Rock I/Teenbeat, Rock II/Tango, Slow Rock/Ballade, Soul/Samba, Waltz/Jazz Waltz, Bossa Nova/Mambo
- Rhythm Controls: Synchro Start, Touch Switch, Rhythm Volume, Balance, Tempo

Fill-In:

Rhythmic Accompaniment: Piano, Guitar.....Accompaniment Volume

Auto-Play-Chord:

Walking Bass One Finger, Fingered, Memory, Cancel

Symphonic Arpeggio:

Voices.....Harp, Strings, Tempo...Fast, Pattern.....I/II, Arpeggio Volume

Program Chord Computer:

Record, Recall, Program I, Program II, Reset (Battery Check), Forward Key, Back Key, End Key, Half Key, Whole Key

Others:

Power Switch, Main Volume, Expression Pedal, Headphone Jack, Input Jack, Output Terminal, Microphone Jack (with Volume), Glide Control, Power Indicator

Maximum Output:

70W

Speakers:

30cm×1, 20cm×1, 6.5cm×1

Power Requirement:

AC 120/220/240V 50/60Hz
AC 120V 60Hz.....Only for Canada

Power Consumption:

170W

Batteries:

1.5V Batteries×3 (for Memory Backup)

Cabinet Dimensions:

112.6cm(W)×58.3cm(D)×97.9cm(H)

Net Weight:

63kg

(without bench)


Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan


CONTENTS

LOCATION OF CONTROLS	2	SOLO 1 CIRCUIT BOARD (SOL1)	40
KEYBOARD RANGES	4	SOLO 2 CIRCUIT BOARD (SOL2)	41
DISASSEMBLY INSTRUCTIONS	5	SOLO 2 CIRCUIT DIAGRAM (SOL2)	42
PRECAUTIONS FOR REPAIR	7	PEDAL TONE FILTER CIRCUIT DIAGRAM (PTF)	43
MEASUREMENTS AND ADJUSTMENTS	9	PEDAL TONE FILTER CIRCUIT BOARD (PTF)	44
ADDRESS MAP TABLE	11	MULTI TREMOLO CIRCUIT BOARD (MT)	45
SX-U50 BLOCK DIAGRAM	14	MULTI TREMOLO CIRCUIT DIAGRAM (MT)	46
MOTHER CIRCUIT BOARD (MB)	15	STRING ENSEMBLE CIRCUIT DIAGRAM (STE)	47
SX-U50 WIRING DIAGRAM	16	STRING ENSEMBLE CIRCUIT BOARD (STE)	48
SYSTEM ASSIGNER 1 BLOCK DIAGRAM	17	CELESTE CIRCUIT BOARD (CEL)	49
SYSTEM BLOCK DIAGRAM OF THIS UNIT	18	CELESTE CIRCUIT DIAGRAM (CEL)	50
SYSTEM ASSIGNER 1 CIRCUIT BOARD (SAS1)	19	REVERB, MIXING CIRCUIT DIAGRAM (RME)	51
SYSTEM ASSIGNER 1 CIRCUIT DIAGRAM (SAS1)	20	REVERB, MIXING CIRCUIT BOARD (RME)	52
SYSTEM ASSIGNER 2 CIRCUIT DIAGRAM (SAS2)	21	AUTO PLAY CHORD SWITCH CIRCUIT	
SYSTEM ASSIGNER 2 CIRCUIT BOARD (SAS2)	22	BOARD (APCS)	53
TONE GENERATOR 1 CIRCUIT BOARD (TG1)	22	AUTO PLAY CHORD SWITCH CIRCUIT	
TONE GENERATOR 1 BLOCK DIAGRAM	23	DIAGRAM (APCS)	54
TONE GENERATOR 1 CIRCUIT DIAGRAM (TG1)	24	RHYTHM CIRCUIT DIAGRAM (RHY)	55
TONE GENERATOR 2 CIRCUIT DIAGRAM (TG2)	25	RHYTHM CIRCUIT BOARD (RHY)	56
TONE GENERATOR 2 CIRCUIT BOARD (TG2)	26	SUSTAIN VOLUME CIRCUIT DIAGRAM (SUSV)	57
TONE GENERATOR (TG3, TG4, TG5)		SUSTAIN VOLUME CIRCUIT BOARD (SUSV)	57
CIRCUIT BOARD	26	JACK CIRCUIT DIAGRAM (JACK)	57
UPPER FLUTE FILTER CIRCUIT DIAGRAM (UFF)	27	JACK CIRCUIT BOARD (JACK)	57
UPPER FLUTE FILTER CIRCUIT BOARD (UFF)	28	MANUAL KEYBOARD CIRCUIT DIAGRAM (MKB)	58
UPPER ORCHESTRAL FILTER CIRCUIT		MANUAL KEYBOARD CIRCUIT BOARD (MKB)	58
BOARD (UOF)	29	PEDAL KEYBOARD CIRCUIT DIAGRAM (PKB)	58
UPPER ORCHESTRAL FILTER CIRCUIT		PEDAL KEYBOARD CIRCUIT BOARD (PKB)	58
DIAGRAM (UOF)	30	CONTROL PANEL RIGHT CIRCUIT BOARD (CPR)	59
LOWER TONE FILTER CIRCUIT DIAGRAM (LTF)	31	CONTROL PANEL LEFT CIRCUIT BOARD (CPL)	59
LOWER TONE FILTER CIRCUIT BOARD (LTF)	32	CONTROL PANEL RIGHT CIRCUIT DIAGRAM (CPR) ...	60
SELECTOR CIRCUIT BOARD (SEL)	33	CONTROL PANEL LEFT CIRCUIT DIAGRAM (CPL)	61
SELECTOR CIRCUIT DIAGRAM (SEL)	34	EXPRESSION CIRCUIT DIAGRAM (EXP)	62
UPPER ORCHESTRAL PRESETS CIRCUIT		EXPRESSION CIRCUIT BOARD (EXP)	62
DIAGRAM (UOP)	35	AMP & POWER SUPPLY CIRCUIT BOARD (AS)	63
UPPER ORCHESTRAL PRESETS CIRCUIT		AC POWER CIRCUIT BOARD (ACP)	63
BOARD (UOP)	36	AMP UNIT CIRCUIT DIAGRAM (AS)	64
PERCUSSIVE PRESETS CIRCUIT BOARD (PPR)	37	EXPLODED VIEWS OF PEDAL KEYBOARD	65
PERCUSSIVE PRESETS CIRCUIT DIAGRAM (PPR)	38	EXPLODED VIEWS OF MANUAL KEYBOARD	66
SOLO 1 CIRCUIT DIAGRAM (SOL1)	39	REPLACEMENT PARTS LIST	67


LOCATION OF CONTROLS




[Photo-1]




[Photo-2]



[Photo-3]



[Photo-4]




[Photo-5]

KEYBOARD RANGES

Upper Keyboard44 Keys f to c⁴ (3 $\frac{2}{3}$ Octaves)
 Lower Keyboard44 Keys F to c³ (3 $\frac{2}{3}$ Octaves)
 Pedal Keyboard13 Keys C to c (1 Octave)


※ An 8-foot compass is used for each keyboard.



DISASSEMBLY INSTRUCTIONS

1. Top Cover

- Remove the 2 setscrews **A** located on the right and left sides of the top cover.
- Remove the 2 setscrews **B** and 4 setscrews **C** located on the rear panel.
- The top cover can be removed upwards.



[Photo-6]

2. Sliding Cover


- After removing the top cover, remove the sliding cover in its fully-closed position.

3. Rear Panel

- Remove the 10 setscrews **C** to detach the rear panel.

4. Control Panel


- Remove both top cover and sliding cover according to procedure 1 and 2.
- Remove the 2 setscrews **D** at both sides of the control panel. Then the control panel can be opened upwards.



[Photo-7]

5. Upper Keyboard

- Open the control panel according to procedure 1, 2 and 4.
- Remove the 2 setscrews **E** on the bottom of the shelf-board.
- Then the upper keyboard can be opened upwards.



[Photo-8]

6. Lower Keyboard


- Open the upper keyboard according to procedure 5.
- Remove the 4 setscrews **F** on the bottom of the shelf-board.
- Then the lower keyboard can be opened upwards.

7. External Jack

- Open the upper keyboard according to procedure 5.
- Remove the 3 setscrews **G** which secure the chassis of the jack. Then, the external jack can be removed.

8. Printed Circuit Board (Mother Board)


- Remove both top cover and sliding cover according to procedure 1 and 2.
- Remove the 4 setscrews **H** on the right and left sides of the printed circuit board retainer plate.
- Each printed circuit board can be removed from the connector of the mother board.



[Photo-9]

9. Expression Unit

- Remove the rear panel according to procedure 3.
- Remove the 3 setscrews which secure the expression case. The expression case can be removed.
- The expression unit can be detached by removing the 4 setscrews ❶.
- when replacing the expression lamp, remove the lamp retainer rubber and detach the lamp from the socket.




[Photo-10]

10. Pedal Keyboards

- Remove the rear panel according to procedure 3.
- Remove the 7 setscrews ❶ which secure the pedal keyboard chassis.
- Lift the cabinet body, and remove the pedal keyboard from the bottom plate of the cabinet.

11. Removing Manual Keys


- Open the manual keyboard according to procedure 5 and 6.
 - As shown in Fig.-1, introduce the key-remover tool vertically between the notches of the manual key that is going to be removed. Move the key-remover tool in the keyboard direction until the notches move enough to disengage from the chassis holes. (The black keys may be removed, after the white keys to either side have been removed, by pulling the front part of the key.)
- ★ If the key-remover tool is not available, the key can be removed by pulling the front part of the key and disengaging it from the chassis while spreading each notched leg outwards.



[Fig.-1]

12. Installation of Manual Keys

- Mount spring "A" on the keyboard chassis.
- Set the key into the key guide and the actuator into the hole in the chassis.
- Press the key in the direction indicated by ❸ in Fig.-2 so that the key pushes down on the spring "A".
- While pushing in direction ❸, pull key towards you so that the key notches engage in the chassis holes.
- The key is correctly installed when the notches of the key are engaged in the chassis holes.




[Fig.-2]

13. Manual Keyboard Switch Unit

- Remove the setscrews of the switch unit on the back of the manual keyboard.
- Unsolder the printed board and pull out the switch unit.

14. Control Knobs, Buttons


- All knobs and buttons can be pulled out. (It is advisable to use a string to remove knobs and buttons.)



[Fig.-3]

15. Tang Switches


- (a) Open the control panel according the procedure 4.
- (b) Remove the printed circuit board on the back of the control panel.
- (c) Shift the tang switch lever down, and remove the damper.
- (d) Remove the spring, and the lever from the chassis.
- (e) Unsolder the switch lead leg.
- (f) Remove the switch while pressing the switch claws inwards as in Photo-11-Ⓐ.



[Fig.-4]


16. Orchestral Conductor Switches

- (a) Open the control panel according to procedure 4.
- (b) Remove the printed circuit board on the right side of the back of the control panel.
- (c) The button switch can be pulled out.
- (d) To remove the LED, unsolder the printed circuit board, and then pull out the LED upwards.
- (e) To remove the switch, unsolder the printed circuit board, and pull out the switch while pressing the switch claws inwards as in Photo-11-Ⓑ.



(Photo: SX-U60)

[Photo-11]



[Fig.-5]




PRECAUTIONS FOR REPAIR

■ Troubles often occur due to faulty operation of your electronic organ if you are not completely familiar with its mechanisms. Therefore, if your organ shows the following symptoms, please check the instrument before repair.

Symptoms	Causes and Measures
Bass is high-pitched, and treble is low-pitched.	Electronic organs are tuned by integral overtones since the overtone composition is integer-multiple. However, human ears feel the bass of pedal keyboard a little higher-pitched, and the treble of upper keyboard a little lower-pitched.
No sound is produced except rhythm.	No sound is produced if the “composer” button of the voice setting computer is turned on with nothing stored in the memory. In that case, push the cancel button.
Upper and lower keyboards produce no sound.	No sound is produced if the tone tablets and buttons of the group which lights up in the orchestral conductor are not turned on. Turn on the desired tablets and buttons.
Pedal keyboards, string ensemble, and solo synthe presets produce no sound.	Control knobs are provided for producing these sounds. No sound is produced with the knobs set an “0”. Set them to the desired volume positions.
Neither lower keyboards nor pedal keyboard produces sound.	If the “recall” button is turned on while no chord is memorized in the program chord computer, neither lower keyboard nor pedal keyboard produces sound. Turn off the “recall” button by pushing the “cancel” button.

Symptoms	Causes and Measures
Only 8 tones are produced when 9 or more keys of the upper keyboard or lower keyboard are simultaneously pressed.	It is designed so that the upper and lower keyboards can produce only up to 8 tones necessary for playing. The 8 keys are given priority over high-pitched tones.
Upper keyboard or lower keyboard produces only up to 4 tones.	with the harmonic coupler turned on, only up to 4 tones can be simultaneously produced by the keyboard.
Pedal keyboard and/or lower keyboard keep sounding.	This trouble occurs when either "one-finger" or "fingered" button of the auto play chord, and "memory" button are turned on. Set the "memory" button to OFF.
When two keys of pedal keyboard are pressed at the same time, only one tone is produced.	If the pedal keyboard keys are depressed fast, the produced sound becomes flat due to mixture of tones. To prevent this, it is designed so that the previous tone is cancelled on depression of other key. When two or more keys are depressed simultaneously, the lowest tone will be produced. (Bass priority)
• Different tones cannot be obtained by changing tone tablets or buttons. • Different effects cannot be obtained by changing effect tablets.	When the voice setting computer is selected, changing the tone tablets or buttons and the effect tablets gives no change. To achieve new tones or effects, push the "cancel" button of the voice setting computer or the upper orchestral conductor button.
Tone tablet sound is not given sustain even when sustain tablet is activated.	In orchestral conductor, the sustain tablet works only for tab voices and percussive presets. When the other buttons are selected, the sustain automatically becomes ineffective so that the instrument is kept in optimum conditions.
Tone tablet sound is not given vibrato even when vibrato tablet is activated.	In upper orchestral conductor, when other than tab voices (such as orchestral presets, percussive presets, string ensemble) are activated, the vibrato tablet automatically becomes ineffective so that the instrument is kept in optimum conditions.
Chorus, tremolo and celeste do not always work when activated.	It is designed so that the characteristic of each individual tone is best used.
It is hard to apply brilliance effect to flute sounds.	Flute sounds are very beautiful and soft, using less overtone. Since the brilliance effect is intended to regulate the overtone of treble range, it is not so much applied to flute sounds as compared with string sounds that contain much more overtone.
Manual balance lever does not work for sounds other than tab voices.	The lever is set so that it is most effective when used individually or in combination.
Rhythm does not start even when accompaniment is played with "synchro" start button depressed.	Rhythm does not start if the "record" button of program chord is turned on. Turn off the button by pushing the "cancel" button.
Fill-in seems to be out of order.	It is because "fill-in" is given instantaneously when the "fill-in and intro" button is turned on. However, there is no chance of getting out of order because "fill-in" is terminated at the end of a bar.
During auto accompaniment, sounds other than the rhythmic accompaniment are not played in rhythm.	It is because the sounds are given more orchestral effects in this way.
Nothing is stored in the memory when program chord computer is used.	• Check that the "record" button is on. Pushing the "one-finger" or "fingered" button causes the "record" button to turn off, making it impossible to memorize. • Do not release the left hand (chord) before pushing the "whole" or "half" key.

MEASUREMENTS AND ADJUSTMENTS

ADJUSTMENT	SETTING	METER USED	ADJUSTMENT CIRCUIT BOARD	ADJ. POINT	CONNECT METER TO	METER READING
Expression characteristics	orchestral conductor...tab voices upper tone tabflute 16' flute 8' flute 4' main volumemax brilliance.....bright upper keyboardC3, E3, G3	High imped- ance volt- meter (VTVM)	Reverb, Mixing Circuit	VR2	30cm Speaker	40±5dB
	Make the expression pedal maximum, and set the high impedance voltmeter to 0dB by the manual balance lever. Next, adjust VR2 so that the range of alteration is 40dB when the expression pedal is minimum.					
Manual level (channel 1)	orchestral conductor...tab voices upper tone tabflute 16' flute 8' flute 4'	High impedance voltmeter (VTVM)	Reverb Mixing Circuit	VR3	30cm Speaker	4±0.3Vrms
Manual level (channel 2)	manual balanceupper brilliance.....bright main volumemax expression pedalmax upper keyboardC3, E3, G3	High impedance voltmeter (VTVM)	Reverb Mixing Circuit	VR4	20cm Speaker	2.5±0.2Vrms
Pedal level	pedal tone tabbass 8' main volumemax expression pedalmax pedal volumemax pedal sustainshort pedal keyboardA1 key	High impedance voltmeter (VTVM)	Pedal Tone Filter Circuit	VR1	30cm Speaker	11±1Vrms
Reverb depth	orchestral conductor...tab voices upper tone tabflute 16' flute 8' flute 4' brilliance.....bright manual balanceupper main volumemax expression pedalmax vibratoon upper keyboardC3~C4 (only for natural key)	High impedance voltmeter (VTVM)	Reverb Mixing Circuit	VR1	20cm Speaker	4±0.3Vrms
	Remove C16 (0.068μ) of the reverb mixing circuit. Connect the VTVM to 20cm speaker and then adjust VR1 so that the VTVM indicates 4 Vrms.					
Solo synthe presets VCF adjustment	orchestral conductor...solo synthe presets trumpeton	Oscilloscope	Solo 1 Circuit	VR1	30cm Speaker	
	Apply 420Hz sine wave to IC2 (terminal ①) of solo 2 circuit. Adjust VR1 of solo 1 circuit so that the output waveform of 30cm speaker terminal is maximized.					
Percussive tone click adjustment	orchestral conductor...tab voices percussive tonefull manual balanceupper main volumemax expression pedalmax upper keyboardon/off (repeating)	Oscilloscope	Upper Orchestral Filter Circuit	VR1	30cm Speaker	Under 30mVp-p 
	Adjust VR1 so that the click waveform on the oscilloscope is minimiz- ed when the upper keyboard is turned on/off.					
Rhythmic accomp click adjustment	rhythmstart rhythm volumemin accomp volumemax main volumemax expression pedalmax	Oscilloscope	Lower Tone Filter Circuit	VR1	30cm Speaker	under 30mVpp 
	Adjust VR1 so that the click waveform on the oscilloscope is minimized.					

ADDRESS MAP TABLE


ADDRESS	SITUATION OF DECODER	BUS INPUT OUTPUT	INPUT/OUTPUT BUS NUMBER						REMARKS
			I/O B5	I/O B4	I/O B3	I/O B2	I/O B1	I/O B0	
0	MKB (upper)	IN	C6						upper keyboard
			F#5	G5	G#5	A5	A#5	B5	
			C5	C#5	D5	D#5	E5	F5	
			F#4	G4	G#4	A4	A#4	B4	
			C4	C#4	D4	D#4	E4	F4	
			F#3	G3	G#3	A3	A#3	B3	
			C3	C#3	D3	D#3	E3	F3	
			F#2	G2	G#2	A2	A#2	B2	
	RHY	IN						F2	rhythm selector
			march	rock I	rock II	swing	bossanova	soul	
			waltz	slow rock	tango	rumba	mambo	samba	
			record	cancel		cambi- nation	composer II	composer I	
		OUT	arpeggio fast	arpeggio II	fill-in & intro		variation		rhythm control
			bass drum	snare drum	hi-hat (accent)	rhythmic accomp		hi-hat (closed)	rhythm output
			maracas	rimshot claves	high bongo	low bongo	low canga	cow bell	
			low conga claves	snar drum rolling	cavasa	hi-hat (opened)	fill-in lamp	tempo lamp	
1	MKB (lower)	IN	C5						lower keyboard
			F#4	G4	G#4	A4	A#4	B4	
			C4	C#4	D4	D#4	E4	F4	
			F#3	G3	G#3	A3	A#3	B3	
			C3	C#3	D3	D#3	E3	F3	
			F#2	G2	G#2	A2	A#2	B2	
			C2	C#2	D2	D#2	E2	F2	
			F#1	G1	G#1	A1	A#1	B1	
	APCS	IN						F1	rhythm start pedal keyboard
			C2			touch switch	synchro switch	foot switch	
			F#1	G1	G#1	A1	A#1	B1	
			C1	C#1	D1	D#1	E1	F1	
									auto-play-chord control
			program II	program I	record	fingered	one-finger	recall	
			techni- chord		normal bass	memory		reset	


ADDRESS		SITUATION OF DECODER	BUS INPUT OUTPUT	INPUT/OUTPUT BUS NUMBER						REMARKS	
				I/O B5	I/O B4	I/O B3	I/O B2	I/O B1	I/O B0		
2	0	CPL	IN								
	1						slow attack	sustain	upper envelope control		
	2					2 ² / ₃ '	4'	full	long	upper percussive tone	
	3				lower 2'		upper 5 ¹ / ₃ '	upper 2 ² / ₃ '		harmonic coupler	
	4			saxophone	accordion	clarinet	trombone	wah brass		orchestral prets	
	5			upper string ensemble II	orchestral preset full	bass guitar	tuba 16'	bass 8'	bass 16'	bass tablets, others	
	6					string 4'	string 8'	oboe 8'	brass 16'	upper tone tablets	
	7			flute 1'	flute 2'	flute 2 ² / ₃ '	flute 4'	flute 8'	flute 16'		
	8	CPR	IN	string 4'	cello 8'	horn 8'	diapason 8'	flute 4'	flute 8'	lower tone tablets	
	9			percussive preset full	tremolo	vibrato				vibrato control	
						on	delay	heavy			
	A			orchestral preset celeste	solo celeste	lower tab celeste	lower tab tremolo	upper tab celeste	upper tab tremolo	sound effect selector	
	B					mandolin	vibraphone	harpsi-chord	piano	percussive presets	
	C			cosmic wah	jazz flute	trampet	saxophone	trombone	violin	solo synthesizer presets	
	D				sustain					lower envelope control	
	E			organ presets	tab voices	string ensemble	solo synthe presets	percussive presets	orchestral presets	upper orchestral conductor	
	F		tab voices	string ensemble	solo synthe presets	percussive presets		lower orchestral conductor			
3	0	SAS2	OUT	15V	upper string ensemble II	orchestral preset full	bass guitar	tuba 16'	bass 8'	bass 16'	bass tablets, others
	1			15V			string 4'	string 8'	oboe 8'	brass 16'	upper tablets
	2			15V	flute 1'	flute 2'	flute 2 ² / ₃ '	flute 4'	flute 8'	flute 16'	
	3			15V	string 4'	cello 8'	horn 8'	diapason 8'	flute 4'	flute 8'	lower tablets
	4			15V	percussive preset full	tremolo	lower string ensemble on	upper string ensemble on		upper percussive preset on	other controls
	5			15V	orchestral preset celeste	solo celeste	lower tab celeste	lower tab tremolo	upper tab celeste	upper tab tremolo	sound effect selector
	6			15V	solo presets key data					solo data change	solo synthe presets control
				BP3	BP2	BP1	BP0				
	7			15V			2 ² / ₃ '	4'	full	long	percussive tone
	8	SAS2	OUT								
	9			15V	saxophone	accordion	clarinet	trombone	wah brass		orchestral presets
	A			15V			mandolin	vibraphone	harpsichord	piano	percussive presets
	B			15V	cosmic wah	jazz flute	trampet	saxophone	trombone	violin	solo synthesizer presets
	C				organ presets	tab voices	string ensemble	solo synthe presets	percussive presets	orchestral presets	upper orchestral conductor display
	D					tab voices	string ensemble	solo synthe presets	percussive presets		lower orchestral conductor display
	E				record	cancel		combination	composer II	composer I	voice setting computer display
	F			15V	percussive preset key down	upper key down	bisy		percussive preset trigger		key down status


MEMO

Lined area for writing the memo.


SX-U50 BLOCK DIAGRAM









MOTHER CIRCUIT BOARD (MB)







SX-U50 WIRING DIAGRAM




SYSTEM ASSIGNER 1 BLOCK DIAGRAM



SYSTEM BLOCK DIAGRAM OF THIS UNIT




SYSTEM ASSIGNER 1 CIRCUIT DIAGRAM (SAS1)




NOTES:

- IC'S
- IC1: SVIGTC4049BP
- IC2: SVIGM74LS05
- IC3, 4, 14: SVIGM74LS08
- IC5, 6: SVIGM74LS75
- IC7: SVIGD5011LC
- IC8: SVIGM74LS138
- IC9: SVIGD2316675
- IC10, 11: SVIGM74LS74
- IC12: SVIGM74LS04
- IC13: SVIGM74LS293
- IC15: SVIGM74LS00
- IC16: SVIGD8049037
- IC17: AN6914
- IC18: SVIGTC4066BP
- DIODES
- D1~3: MA1501R
- BLOCK RESISTORS
- Z3, 6: EXBP88472M
- Z2, 4, 5: EXBP88102M
- Z1: EXBP88152M


Block Resistor





SYSTEM ASSIGNER 2 CIRCUIT BOARD (SAS2)


SXPG10021



- NOTES:**
- IC'S
 - IC1, 2: SVIGM74LS138
 - IC3, 4, 5: SVIGM53207
 - IC6: SVIGM74LS367
 - IC7: SVIGM74LS174
 - IC8: SVIGTC4066BP
 - IC9: AN6552
 - TRANSISTORS
 - Q1, 2: 2SC1047C
 - Q3, 4: 2SC2828AQRS
 - DIODES
 - D1~5: MA1501R


TONE GENERATOR 1 CIRCUIT BOARD (TG1)

SXPG10031



- NOTES:**
- TG1 • IC'
 - IC1, 10: SVIGMC5227
 - IC11: SVIGM74LS74
 - IC2~9: AN6551F
 - TG3 • DIODES
 - D1~8: SVDG1SS53
 - BLOCK RESISTORS
 - Z1, 2: EXBP84475K
 - Z3: EXBP86684K
 - TG4 • TRANSISTORS
 - Q1, 2: 2SC2377C
 - DIODE
 - D1: MA1501R
 - TG5 • TRANSISTORS
 - Q1~3: 2SC2377C
 - DIODES
 - D1, 2: MA1501R

TONE GENERATOR 1 BLOCK DIAGRAM



TONE GENERATOR 1 CIRCUIT DIAGRAM (TG1)

A

B

C

D

E

F

1

2

3

4


5

6

7

8


9





TONE GENERATOR 2 CIRCUIT BOARD (TG2)


SXP G10042



- NOTES:
• IC'S
IC1: SVIGMC5227
IC9: SVIGM74LS74
IC2~5: AN6552F
• TRANSISTOR
Q1: 2SC2377C
• DIODE
D1: MA150IR


TONE GENERATOR (TG3, TG4, TG5) CIRCUIT BOARD

TG3
SXP G10331




- NOTES:
• CAPACITORS
C1~8: (MS) 50V0.22
• DIODES
D1~8: SVDG1SS53
• BLOCK RESISTORS
Z1, 2: EXBP84475K
Z3: EXBP88684K

TG4
SXP G10391




- NOTES:
• TRANSISTORS
Q1, 2: 2SC2377C
• DIODES
D1: MA150IR

TG5
SXP G10471



- NOTES:
• TRANSISTORS
Q1~3: 2SC2377C
• DIODES
D1, 2: MA150IR


UPPER FLUTE FILTER CIRCUIT DIAGRAM (UFF)



NOTES:
 • IC'S
 IC1~5: AN6552F
 • TRANSISTORS
 Q1~14: 2SC828T

UPPER FLUTE FILTER CIRCUIT BOARD (UFF)


SXPGA10051



- NOTES:**
- IC'S
 - IC1~5: AN6552F
 - TRANSISTORS
 - Q1~14: 2SC828T

UPPER ORCHESTRAL FILTER CIRCUIT BOARD (UOF)


SXPGB10051



NOTES:


- IC'S
IC1~3: SVIGTC40174B
IC4: AN6552F
IC5: SVIGBA6110
IC6~8: SVIGTC4066BP
- TRANSISTORS
Q1~5: 2SC1328T
Q6~8: 2SC828AQRS
- DIODES
D1~6: MA150IR

UPPER ORCHESTRAL FILTER CIRCUIT DIAGRAM (UOF)




- NOTES:**
- IC'S
 - IC1~3: SVIGTC40174B
 - IC4: AN6552F
 - IC5: SVIGBA6110
 - IC6~8: SVIGTC4066BP
 - TRANSISTORS
 - Q1~5: 2SC1328T
 - Q6~8: 2SC828AQRS
 - DIODES
 - D1~6: MA150IR

LOWER TONE FILTER CIRCUIT DIAGRAM (LTF)



- NOTES:**
- IC'S
 - IC1~4: AN6552F
 - IC5: SVIGTC40174B
 - IC6, 7: SVIGTC4066BP
 - IC8: SVIGBA6110
 - TRANSISTORS
 - Q1~9: 2SC1328T

A horizontal number line with arrows at both ends. There are major tick marks at every integer from 0 to 5, labeled with the numbers 1, 2, 3, 4, and 5 above the line. There are also minor tick marks between each pair of major tick marks, representing the halfway points (0.5, 1.5, 2.5, 3.5, 4.5).


SXPGA10061

NOTES:

- IC'S
IC1~4: AN6552F
IC5: SVIGTC40174B
IC6, 7: SVIGTC4066BP
IC8: SVIGBA6110
- TRANSISTORS
Q1~9: 2SC1328T

SELECTOR CIRCUIT BOARD (SEL)


SXPGB10061




NOTES:

- IC'S
- IC1~4: SVIGBA6110
- IC5, 6, 13, 14: AN6552F
- IC7~9: SVIGTC4066BP
- IC10, 12: SVIGTC40174B
- IC11: SVIGTC4001BP

SELECTOR CIRCUIT DIAGRAM (SEL)




UPPER ORCHESTRAL PRESETS CIRCUIT DIAGRAM (UOP)



- NOTES:**
- IC'S
 IC1~3: SVIGBA6110
 IC4~7: SVIGTC4066BP
 IC8: SVIGTC40174B
 - TRANSISTORS
 Q1, 4, 7, 8: 2SC828AQRS
 Q2, 3, 6: 2SA1015GR
 Q5: 2SA798AFG2
 - DIODES
 D1~20: MA1501R

UPPER ORCHESTRAL PRESETS CIRCUIT BOARD (UOP)

SXPGA10071




NOTES:

- IC'S
 - IC1~3: SVIGBA6110
 - IC4~7: SVIGTC4066BP
 - IC8: SVIGTC40174B
- TRANSISTORS
 - Q1, 4, 7, 8: 2SC828AQRS
 - Q2, 3, 6: 2SA1015GR
 - Q5: 2SA798AFG2
- DIODES
 - D1~20: MA1501R

PERCUSSIVE PRESETS CIRCUIT BOARD (PPR)


SXPGB10072



NOTES:


- IC'S
 - IC1, 3: AN6552F
 - IC2, 7: SVIGTC4066BP
 - IC4: SVIGBA6110
 - IC5, 6: SVIGTC40174B
 - IC8: SVIGTC4013BP
- TRANSISTORS
 - Q1, 2: 2SC1328T
 - Q3~5, 7, 8: 2SC828AQRS
 - Q6: 2SA1015GR
- DIODES
 - D1~6, 9: MA1501R

PERCUSSIVE PRESETS CIRCUIT DIAGRAM (PPR)



- NOTES:**
- IC'S
 - IC1, 3: AN6552F
 - IC2, 7: SVIGTC4066BP
 - IC4: SVIGBA6110
 - IC5, 6: SVIGTC40174B
 - IC8: SVIGTC4013BP
 - TRANSISTORS
 - Q1, 2: 2SC1328T
 - Q3~5, 7, 8: 2SC828AQRS
 - Q6: 2SA1015GR
 - DIODES
 - D1~6, 9: MA150IR

SOLO 1 CIRCUIT DIAGRAM (SOL1)



NOTES:

- IC'S
- IC1, 2: SVIGTC40174B
- IC3: SVIGTC4013BP
- IC4, 5: AN6552
- IC6: AN6914
- IC7, 8: SVIGTC4069BP

• TRANSISTORS:


- Q1, 4, 6, 9, 10: 2SC828AQRS
- Q2, 7: 2SA798AFG2
- Q3, 8: 2SA1015GR
- Q5: 2SK117BL

• DIODES

- D1, 2, 4~6, 12~17, 19~22, 24, 25, 31, 32, 34: MA1501R

SOLO 1 CIRCUIT BOARD (SOL1)

SXPGA10082



NOTES:

- IC'S
- IC1, 2: SVIGTC40174B
- IC3: SVIGTC4013BP
- IC4, 5: AN6552
- IC6: AN6914
- IC7, 8: SVIGTC4069BP

• TRANSISTORS:

- Q1, 4, 6, 9, 10: 2SC828AQRS
- Q2, 7: 2SA798AFG2
- Q3, 8: 2SA1015GR
- Q5: 2SK117BL


• DIODES

- D1, 2, 4~6, 12~17, 19~22, 24, 25, 31, 32, 34:

MA1501R

SOLO 2 CIRCUIT BOARD (SOL2)

SXPGB10082



NOTES:


- IC'S
IC1: SVIGTC4066BP
IC2, 3: SVIGBA6110
IC4, 6: AN6552
IC5: SVIGTC4069BP
- TRANSISTORS
Q8~11, 13, 14: 2SC828AQRS
Q15: 2SA1015GR
Q16, 17: 2SC1047C
- DIODES
D12~18, 21~28: MA1501R

SOLO 2 CIRCUIT DIAGRAM (SOL2)


NOTES:

• IC'S
IC1: SVIGTC4066BP
IC2, 3: SVIGBA6110
IC4, 6: AN6552
IC5: SVIGTC4069BP

• TRANSISTORS
Q8~11, 13, 14: 2SC828AQRS
Q15: 2SA1015GR
Q16, 17: 2SC1047C
• DIODES
D12~18, 21~28: MA1501R



PEDAL TONE FILTER CIRCUIT DIAGRAM (PTF)




NOTES:

- IC'S
 - IC1: SVIGTC4013BP
 - IC2: SVIGTC40174B
 - IC3: SVIGTC4073BP
 - IC4: SVIGTC4081BP
 - IC5, 6: AN6552F
- TRANSISTORS
 - Q1, 2, 4~6, 8~12, 17~25: 2SC828AQRS
 - Q13~16, 27, 29: 2SC1328T
 - Q26, 28: 2SK117BL
- DIODES
 - D1, 3~16: MA1501R

PEDAL TONE FILTER CIRCUIT BOARD (PTF)

SXPGA10091




NOTES:

- IC'S
- IC1: SVIGTC4013BP
- IC2: SVIGTC40174B
- IC3: SVIGTC4073BP
- IC4: SVIGTC4081BP
- IC5, 6: AN6552F

- TRANSISTORS
- Q1, 2, 4~6, 8~12, 17~25: 2SC828AQRS
- Q13~16, 27, 29: 2SC1328T
- Q26, 28: 2SK117BL
- DIODES
- D1, 3~16: MA150IR

MULTI TREMOLO CIRCUIT BOARD (MT)


SXPGB10091




NOTES:

- IC'S
IC1, 3: MN3006
IC2, 4: SVIGBA6110
IC5, 6: AN6552
IC7, 8: SVIGMSM4011
- TRANSISTORS
Q1~6: 2SC1328ST
Q7~9: 2SC828T
- DIODES
D3~11: MA1501R

MULTI TREMOLO CIRCUIT DIAGRAM (MT)



STRING ENSEMBLE CIRCUIT DIAGRAM (STE)



NOTES:


• IC'S
IC1, 3, 5: SVIGMSM4011
IC2, 4, 6: MN3006
IC7: AN6552F

• TRANSISTORS
Q1~10: 2SC828AQRS
Q11~18: 2SC1328T

• DIODES
D1~D7: MA1501R

STRING ENSEMBLE CIRCUIT BOARD (STE)


SXPG10103



NOTES:

- IC'S
IC1, 3, 5: SVIGMSM4011
IC2, 4, 6: MN3006
IC7: AN6552F
- TRANSISTORS
Q1~10: 2SC828AQRS
Q11~18: 2SC1328T
- DIODES
D1~D7: MA1501R


CELESTE CIRCUIT BOARD (CEL)

SXPG10102


NOTES:

- IC'S
 - IC1, 3, 5: SVIGMSM4011
 - IC2, 4, 6: MN3004
 - IC7: AN6552F
- TRANSISTORS
 - Q8~10: 2SC828AQRS
 - Q11~19: 2SC1328T
- DIODES
 - D2~7: MA150IR

CELESTE CIRCUIT DIAGRAM (CEL)




REVERB, MIXING CIRCUIT DIAGRAM (RME)



REVERB, MIXING CIRCUIT BOARD (RME)

SXPG10112




NOTES:

- IC'S
 - IC1: SVIGLA4031P
 - IC2~4, 6, 8: AN6552F
 - IC5, 7: SVIGBA6110
- TRANSISTORS
 - Q1: 2SC1684RS
 - Q2, 4: 2SC828AQRS
 - Q3, 5: 2SA1015GR
 - Q6, 7: 2SK117BL
- DIODES
 - D1, 2: MA150IR

AUTO PLAY CHORD SWITCH CIRCUIT BOARD (APCS)


SXPG10191



NOTES:

- IC'S
 - IC1: SVIGM74LS138
 - IC2: SVIGM74LS74
- TRANSISTORS
 - Q1, 2: 2SC828AQRS
- DIODES
 - D1~12: MA150IR
 - D13: SVDGSLR54UTA

AUTO PLAY CHORD SWITCH CIRCUIT DIAGRAM (APCS)



- NOTES:**
- IC'S
 - IC1: SVIGM74LS138
 - IC2: SVIGM74LS74
 - TRANSISTORS
 - Q1, 2: 2SC828AQRS
 - DIODES
 - D1~12: MA150IR
 - D13: SVDGSLR54UTA


FIG. 1

NOTES:

- IC'S
 - IC1: SVIGM74LS138
 - IC2: SVIGM74LS75
 - IC3, 4, 5: SVITC40174B
 - IC6: SVIGM74LS04
 - IC7: SVIGTC4001BP
 - IC8: AN6914
 - IC9~14: AN6552F
- DIODES
 - D1~21, 25~33, 35, 36, 38~41, 43, 45: MA1501R
 - D22~24, 46: SVDGLR54UTA
- TRANSISTORS
 - Q1: 2SC1328T (Selected)
 - Q1~5: 2SC1328T
 - Q2, 6: 2SK30AGR


RHYTHM CIRCUIT BOARD (RHY)

SXPG10171




- NOTES:**
- IC'S
 - IC1: SVIGM74LS138
 - IC2: SVIGM74LS75
 - IC3, 4, 5: SVITC40174B
 - IC6: SVIGM74LS04
 - IC7: SVITC4001BP
 - IC8: AN6914
 - IC9~14: AN6552F
 - TRANSISTORS
 - Q1: 2SC1328T (Selected)
 - Q1~5: 2SC1328T
 - Q2, 6: 2SK30AGR
 - DIODES
 - D1~21, 25~33, 35, 36, 38~41, 43, 45: MA150IR
 - D22~24, 46: SVDGSLR54UTA

SUSTAIN VOLUME CIRCUIT DIAGRAM (SUSV)




SUSTAIN VOLUME CIRCUIT BOARD (SUSV)

SXPG10181




JACK CIRCUIT DIAGRAM (JACK)




JACK CIRCUIT BOARD (JACK)

SXPG10261




NOTES:
• TRANSISTORS
Q1, 2: 2SC1328T


MANUAL KEYBOARD CIRCUIT DIAGRAM (MKB)




PEDAL KEYBOARD CIRCUIT DIAGRA




MANUAL KEYBOARD CIRCUIT BOARD (MKB)



PEDAL KEYBOARD CIRCUIT BOARD (PKB)




PEDAL KEYBOARD CIRCUIT DIAGRAM (PKB)




(PKB)

SXPG10201




B)


SXPG10211



CONTROL PANEL RIGHT CIRCUIT BOARD (CPR)




CONTROL PANEL LEFT CIRCUIT BOARD (CPL)



CONTROL PANEL RIGHT CIRCUIT BOARD (CPR)

SXPGA10141




NOTES:

- IC: SVIGM74LS138
- DIODES: D1~31: MA150IR
- LEDS: LED1~5: SVDGSLR54UTA

CONTROL PANEL LEFT CIRCUIT BOARD (CPL)


SXPGB10141



NOTES:


- IC: SVIGM74LS138
- DIODES: D1~27: MA150IR

CONTROL PANEL RIGHT CIRCUIT DIAGRAM (CPR)




- NOTES:**
- IC: SVIGM74LS138
 - DIODES: MA150IR
 - LED1~5: SVDGSLR54UT

CONTROL PANEL LEFT CIRCUIT DIAGRAM (CPL)




EXPRESSION CIRCUIT DIAGRAM (EXP)




EXPRESSION CIRCUIT BOARD (EXP)

SXPG10322



AMP & POWER SUPPLY CIRCUIT BOARD (AS)

SXPG10231




NOTES:

- IC'S
 - IC1: SVIGSTK461
 - IC2: SVIGUPC7815H
 - IC3: AN6552
 - IC4: SVIGUPC7805H
 - IC5: SVIGHA17806P
- TRANSISTORS
 - Q1: 2SC828AQRS
 - Q2: 2SB761P
- DIODES
 - D1, 2: SVDS2VB10
 - D3: SVDS2VC10
 - D4, 6, 9: MA1501R
 - D8: SVDO5Z20A


AC POWER CIRCUIT BOARD (ACP)

SXPG10411




* Product for
Canada Only


SXPG10431




AMP UNIT CIRCUIT DIAGRAM (AS)



EXPLODED VIEWS OF PEDAL KEYBOARD



EXPLODED VIEWS OF MANUAL KEYBOARD



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
	ESK3219V	Upper Keyboard Assembly	K-14	K30KG74	Key Guide (7 Continuous)
	ESK3220V	Lower Keyboard Assembly	K-15	K30KG73	Key Guide (12 Continuous)
K-1	K30WK61C	Natural Key (Highest C Key)	K-16	K30KG72	Key Guide (13 Continuous)
K-2	K30WK60E	Natural Key (E Key)	K-17	K30DP49B	Felt
K-3	K30WK60D	Natural Key (D Key)	K-18	K30GG1	Key Guide Rubber
K-4	K30WK60C	Natural Key (C Key)	K-19	K30DP77B	Felt
K-5	K30WK60B	Natural Key (B Key)	K-20	K30VCH7	Chassis
K-6	K30WK60A	Natural Key (A Key)	K-21	K30VSU78A	Switch Unit
K-7	K30WK60G	Natural Key (G Key)	K-22	K30VSU79A	Switch Unit
K-8	K30WK60F	Natural Key (F Key)	K-23	K30VSU80A	Switch Unit
K-9	K30BK59	Sharp Key	K-24	K30VSU77A	Switch Unit
K-10, 11	K30AT66	Actuator Rubber			
K-12, 13	K30BN2	Leaf Spring			

REPLACEMENT PARTS LIST

■ ELECTRICAL PARTS

○ New Parts

Part No.	Description	Remarks
PRINTED CIRCUIT BOARDS		
○ SXPG10012	System Assigner 1	
○ SXPG10021	System Assigner 2	
○ SXPG10031	Tone Generator 1	
○ SXPG10042	Tone Generator 2	
○ SXPGA10051	Upper Flute Filter	
○ SXPGB10051	Upper Orchestral Filter	
○ SXPGA10061	Lower Tone Filter	
○ SXPGB10061	Selector	
○ SXPGA10071	Upper Orchestral Presets	
○ SXPGB10072	Percussive Presets	
○ SXPGA10082	Solo 1	
○ SXPGB10082	Solo 2	
○ SXPGA10091	Pedal Tone Filter	
○ SXPGB10091	Multi Tremolo	
○ SXPG10103	String Ensemble	
○ SXPG10102	Celeste	
○ SXPG10112	Reverb, Mixing	
○ SXPG10171	Rhythm	

INTEGRATED CIRCUITS		
○ AN6551F	Operational Amplifier	
○ AN6552F	Operational Amplifier	
○ AN6914	Dual Comparator	
○ MN3004	BBD for Audio Signal Delays (512-stage)	
○ MN3006	BBD for Audio Signal Delays (128-stage)	
○ SVIGTC4001BP	Quadruple 2-Input NOR Gate	
○ SVIGTC4013BP	Dual D-Type Flip-Flop	
○ SVIGTC40174B	Hex D-Type Flip-Flop	
○ SVIGTC4049BP	Hex Inverter	
○ SVIGTC4066BP	Analog Switch	
○ SVIGTC4069BP	Hex Inverter	
○ SVIGTC4073BP	Triple 3-Input AND Gate	
○ SVIGTC4081BP	Quadruple 2-Input AND Gate	
○ SVIGM74LS00	Quadruple 2-Input Positive NAND Gate	
○ SVIGM74LS04	Hex Inverter	
○ SVIGM74LS05	Hex Inverter with Open Collector Output	
○ SVIGM74LS08	Quadruple 2-Input Positive AND Gate	
○ SVIGM74LS74	Dual D-Type Flip-Flop	
○ SVIGM74LS75	4-Bit Bistable Latch	
○ SVIGM74LS138	Decoder	
○ SVIGM74LS174	Hex D-Type Flip-Flop	
○ SVIGM74LS293	4-Bit Binary Counter	
○ SVIGM74LS367	Bus Driver	
○ SVIGM53207	Level Shifter	
○ SVIGMC5227	Tone Generator	
○ SVIGD5101LC	1024-Bit Static RAM	
○ SVIGD2316675	16, 384-Bit Mask Programmable ROM	
○ SVIGD8049037	1 Chip 8-Bit Micro Computer	
○ SVIGBA6110	VCA (Voltage Controlled Amplifier)	
○ SVIGMSM4011	Quadruple 2-Input NAND Gate	
○ SVIGLA4031P	Reverb Drive Amp	
○ SVIGSTK461	Power IC	
○ SVIGUPC7815H	Voltage Regulator	
○ SVIGUPC7805H	Voltage Regulator	
○ SVIGHA17806P	Voltage Regulator	

Part No.	Description	Remarks
TRANSISTORS		
Standard Part	Production Part	
2SA798A-G2	2SA798AFG2	
2SA1015-Y	2SA1015GR	
2SB761-R	2SB761P	
2SC1328-T	2SC828AQRS, 2SC828T	
2SC1047-C	2SC1047C	
2SC1684-R	2SC1684RS	
2SC2377-C	2SC2377C	
2SK30AD	2SK117BL, 2SK30AGR	

DIODES		
MA162A	MA150IR	Switching
SVDG1SS53		Envelope
SVDS2VB10		Rectifier
SVDS2VC10		Rectifier
SM112	SVDG10E1LF	
SVD05Z20A		Zener

COILS, CRYSTAL		
○ EIS10E301Z	Coil for Oscillator	
○ RLQZ1231-Z	Rythm Coil	
○ SVQG43U1598T	Crystal	

LED'S, LAMP		
○ LN29RP	LED (Power Indicator)	
○ SVDGSLR54UTA	LED	
XAMR55P	Expression Lamp	

CDS		
○ SVEG5	Light Sensitive Device	

THERMISTOR		
○ ERTD2FHL333S	Thermistor	

SWITCHES		
○ ESB70291S	Power Switch	
○ ESB70454T	Power Switch (Product for Canada Only)	
○ ESE3758	Voltage Selector	
○ ESB8963	Orchestral Conductor Switch Assembly	
○ [B89VSU104]	Switch	
○ EST236	Tang Switch Assembly	
○ EST235	Tang Switch Assembly	
○ [T23VSU3]	Switch	
○ SSHG8006AA	Percussive Presets,	
	Solo Synthesizer Presets	
○ SSHG9009AA	Upper Orchestral Presets,	
	Harmonic Coupler	

Part No.	Description	Remarks
○ SSHG6005AA	Symphonic Arpeggio,	
○ SSHG2010AA	Rythmic Accompaniment	
○ SSHG5007AA	Rythm A/B, Fill-in & Intro	
○ SSHG8005AA	Voice Setting Computer	
○ SSHG7009AA	Rythm Selector	
○ SSHG4004AA	Auto Play Chord, Techni-Chord	
○ SSHG1017AA	Program Chord, Walking Bass	
○ SSHG1018A	Synchro Start	
○ SSHG14	Touch Start	
○ K30VSU78A	Glide Switch	
○ K30VSU79A	Manual Key Switch Unit	Upper F2~B2 Lower F1~B1
○ K30VSU80A	Manual Key Switch Unit	Upper C3~F3 Lower C2~F2
○ K30VSU77A	Manual Key Switch Unit	Upper F#3~F5 Lower F#2~F4
○ SSHG5006A	Manual Key Switch Unit	Upper F#5~C6 Lower F#4~C5
○ SSHG3012A	Pedal Switches (5 continuous)	
	Pedal Switches (3 continuous)	
VARIABLE RESISTORS		
○ EVA1020A24G	20 KΩA, Main Volume	
○ EVHEVA529A54	50 KΩA, Microphone Volume	
○ EVD725B53G	5 KΩB, Rhythm Balance, Lower Sustain, Upper Sustain, Solo Pitch Control	
○ EVD1125A24G	20 KΩA, Pedal Sustain	
○ EVD825B24G	20 KΩB, Reverb, Brilliance, Tremolo Speed, Pedal Volume, Harmonic Control, Upper String Ensemble Volume, Solo Synthesizer Presets Volume, Lower String Ensemble Volume, Arpeggio Volume, Manual Balance	
○ EVD925B54G	50 KΩB, Rhythm Volume Rhythm Tempo, Accompaniment Volume	
SEMI-FIXED RESISTORS		
○ EVNGOT01B13A	1 KΩ	
○ EVBGOT01B14A	10 KΩ	
○ EVNGOT01B24A	20 KΩ	
○ EVNGOT01B54A	50 KΩ	
○ EVNGOT01B15A	100 KΩ	
BLOCK RESISTORS		
○ EXBP88102M	1 KΩ	
○ EXBP88152M	1.5 KΩ	
○ EXBP88472M	4.7 KΩ	
○ EXBP88684K	680 KΩ	
○ EXBP84475K	4.7 MΩ	
ELECTROLYTIC CAPACITORS		
○ ECET35R472SW	4700μF, 35V	
○ ECNC4A103M	0.01μF, 450V	
○ ECQU1A103ME	0.01μF, 125V (Product for Canada Only)	

Part No.	Description	Remarks
JACKS		
○ SJJG20A	Mic Jack, Aux Jack	
○ SJJG70A	Headphones Jack	
○ SJFG10A	Line Out Terminals	
SPEAKERS		
○ EAS30PL79S	30cm Speaker	
○ EAS20PL163S	20cm Speaker	
○ EAS65PH05ST	6.5cm Speaker	
FUSES		
○ XBA2C16TR0	250V, 1.6A (Time Lag)	
○ XBA2C08TR0	250V, 0.8A (Time Lag)	
○ XBA1E16NS5	125V, 1.6A (Product for Canada Only)	
POWER TRANSFORMERS		
○ SLTG5Q11		
○ SLTG5Q12	(Product for Canada Only)	
AC CORDS, AC OUTLET, PLUG		
○ RJA23ZC-K	AC Cord	
○ SJAG23	AC Cord (Product for Australia Only)	
○ RJA45ZC-K	AC Cord (Product for England and Malaysia Only)	
○ SJAG22	AC Cord (Product for Canada Only)	
○ SJSAG66-2	AC Outlet (Product for Canada Only)	
○ SJP5213-1	Plug for AC Cord (Product for Asia Only)	
ASSEMBLY PARTS		
○ SXVG5020A	EXP Unit	
○ SJUG20801N	Reverb Unit	
○ SHRG550	Cussion for Reverb	

MECHANICAL PARTS

Part No.	Description	Remarks
CABINET		
○ SKZG1100A	Sliding Cover	
○ SKZG1100B	Sliding Cover (Product for Canada Only)	
○ SGXG410A	Ornament for Sliding Cover	
○ SKPG110A	Top Cover	
○ SKPG110B	Top Cover (Product for Canada Only)	
○ SKGG1D60B	Music Rack	
○ SKGG1E10B	Music Rack (Product for Canada Only)	
○ SBHG5003	Hinge for Music Rack	
○ SBLG7	Stay for Music Rack	
○ SKFG2201A	Rear Panel	
○ SKHG5	Handle for Rear Panel	
○ SGWG5061A	Upper Right End Cover Panel	
○ SGWG5061C	Upper Right End Cover Panel (Product for Canada Only)	
○ SYWG4101A	Upper Left End Cover Panel (with LED)	
○ SYWG4101B	Upper Left End Cover Panel (Product for Canada Only)	
○ SGWG3070A	Lower Right End Cover Panel	
○ SGWG3070B	Lower Right End Cover Panel (Product for Canada Only)	
○ SGWG2100A	Lower Left End Cover Panel	
○ SGWG2100B	Lower Left End Cover Panel (Product for Canada Only)	
○ SGWG1170A	Control Panel	
○ SGWG1170B	Control Panel (Product for Canada Only)	
○ SGXG430BS	Ornament Panel for Lower Keyboard	
○ SHRG2020A	Foot for Cabinet	
KNOBS		
○ SBNG4010A	Mic Volume Knob	
○ SBNG11K	Main Volume Knob	
○ SBNG6010G	Slide Volume Knob	
BUTTONS		
○ SBCG20147	Power Switch	
○ SBCG431	Touch Switch (with LED)	
○ B63BT16GA	Yellow (harp)	Symphonic Arpeggio
○ B63BT16GB	Yellow (strings)	
○ B63BT16GC	Yellow (fast)	
○ B63BT16GD	Yellow (I/II)	
○ B63BT16GE	Yellow (piano)	Rythmic Accompaniment
○ B63BT16GF	Yellow (guitar)	
○ B63BT16AB	Beige (march)	Rythm Selector
○ B63BT16EA	Gray (rock I)	
○ B63BT16AC	Beige (slow rock)	
○ B63BT16EB	Gray (waltz)	
○ B63BT16EC	Gray (swing)	
○ B63BT16AD	Beige (rock II)	
○ B63BT16ED	Gray (soul)	
○ B63BT16AE	Beige (bossa nova)	

Part No.	Description	Remarks
○ B63BT16CA	Violet Blue (cancel)	Auto Play Chord
○ B63BT16BA	Sky Blue (record)	
○ B63BT16BB	Sky Blue (recall)	
○ B63BT16BC	Sky Blue (one finger)	
○ B63BT16BD	Sky Blue (fingered)	
○ B63BT16AA	Beige (memory)	
○ B63BT16BE	Sky Blue (program I)	Program Chord
○ B63BT16BF	Sky Blue (program II)	
○ B63BT16BG	Sky Blue (reset)	
○ B63BT16H	Grass Green	(Without Silk Print)
○ B63BT16J	Soft Green	
○ B63BT16C	Violet Blue	
○ B63BT16B	Sky Blue	
○ B63BT16A	Beige	
○ B63BT15DA	Orange (wah brass)	Upper Orchestral Presets
○ B63BT15DB	Orange (clarinet)	
○ B63BT15DC	Orange (accordion)	
○ B63BT15DD	Orange (saxophone)	
○ B63BT15DE	Orange (trombone)	
○ B63BT15EA	Orange (full)	Harmonic Coupler
○ B63BT15CA	Violet Blue (on)	
○ B63BT15CB	Violet Blue (2 ² / ₃ / 5 ¹ / ₃)	
○ B63BT15CC	Violet Blue (2')	
○ B63BT15GB	Yellow (piano)	Percussive Presets
○ B63BT15GC	Yellow (harpsichord)	
○ B63BT15GD	Yellow (vibraphone)	
○ B63BT15GE	Yellow (mandolin)	
○ B63BT15EA	Gray (full)	
○ B63BT15FA	Red (violin)	Solo Synthesizer Presets
○ B63BT15FB	Red (trombone)	
○ B63BT15FC	Red (saxophone)	
○ B89VBT103A	Orchestral Conductor (with LED)	
SWITCH LEVERS		
○ T23VLV2CA	bass 16'	Pedal Tone Lever
○ T23VLV2CB	bass 8'	
○ T23VLV2AA	bass guitar	
○ T23VLV2CC	flute 16'	Upper Tone Lever
○ T23VLV2CD	flute 8'	
○ T23VLV2CE	flute 4'	
○ T23VLV2CF	flute 2 ² / ₃ '	
○ T23VLV2CG	flute 2'	
○ T23VLV2EB	brass 16'	
○ T23VLV2EC	oboe 8'	
○ T23VLV2AB	string 8'	
○ T23VLV2AC	string 4'	
○ T23VLV2DA	sustain	
○ T23VLV2DB	slow attack	

■ WIRING PARTS LIST (See wiring diagram on page 16.)

	Part No.	Description	Remarks
○	T23VLV2CJ	4' } 2 ² / ₃ ' } full } long }	Upper Percussive tone Lever
○	T23VLV2CK		
○	T23VLV2DC		
○	T23VLV2DD		
○	T23VLV2BA	on } heavy } delay }	Vibrato Lever
○	T23VLV2BB		
○	T23VLV2DE		
○	T23VLV2CL	tab voices } chorus/tremolo }	Multi Tremolo Lever
○	T23VLV2FA		
○	T23VLV2CL	tab voices } orchestral presets } solo synthe presets }	Celeste Lever
○	T23VLV2BC		
○	T23VLV2ED		
○	T23VLV2DA	sustain } flute 8' } flute 4' } diapason 8' } horn 8' } cello 8' } string ensemble }	Lower Tone Lever
○	T23VLV2CD		
○	T23VLV2CE		
○	T23VLV2CM		
○	T23VLV2EE		
○	T23VLV2AD		
○	T23VLV2AE		
MANUAL KEYS			
	K30WK60A K30WK60B K30WK60C K30WK60D K30WK60E K30WK60F K30WK60G K30WK61C K30BK59	Natural Key (A Key) Natural Key (B Key) Natural Key (C Key) Natural Key (D Key) Natural Key (E Key) Natural Key (F Key) Natural Key (G Key) Natural Key (Highest Octave C Key) Sharp Key	
PEDAL KEYS			
	STBG1080A STBG2020A	Natural Key Sharp Key	
BENCH			
○	SZ-U1	(Product for Canada Only) (Product for Austraira Only)	
○	SZ-U1NR		
○	SZ-U1R		
INSTRUCTION BOOK			
○	SQFG2710	Instruction Book (Scandinavian)	
○	SQFG2720	Instruction Book (English)	
○	SQFG2730	Instruction Book (French)	
○	SQFG2740	Instruction Book (German)	

Part No.	Description	Remarks
○ SWKG136	Conector, With Wire	
○ SWKG140	Conector, With Wire	
○ SWKG141	Conector, With Wire	
○ SWKG143	Conector, With Wire	
○ SWKG144	Conector, With Wire	
○ SWKG145	Conector, With Wire	
○ SWKG146	Conector, With Wire	
○ SWKG148	Conector, With Wire	
○ SWKG150	Conector, With Wire	
○ SWKG151	Conector, With Wire	
○ SWKG152	Conector, With Wire	
○ SWKG154	Conector, With Wire	
○ SWKG155	Conector, With Wire	
○ SWKG159	Conector, With Wire	
○ SWKG163	Conector, With Wire	
○ SWKG164	Conector, With Wire	
○ SWKG165	Conector, With Wire	
○ SWKG166	Conector, With Wire	
○ SWKG167	Conector, With Wire	
○ SWKG168	Conector, With Wire	
○ SWKG171	Conector, With Wire	
○ SWKG172	Conector, With Wire	
○ SWKG173	Conector, With Wire	